



Squared Edge Zuri Quick Reference Guide

COLORS: Weathered Gray, Pecan, Walnut, Brazilia, Chestnut & Hickory

BOARD SIZES: 5/4" Thick x 6" Wide x 12', 16' & 20' Lengths

TRIM SIZE: 5/4" Thick x 3-1/2" Wide x 2" Height x 12' Length

FASCIA: 3/4" Thick x 7-1/4" Wide x 12' Length and 3/4" Thick x 11-1/4" Wide x 12' Length

JOIST SPACING: *Minimum of 3-1/2" Joist Height & All Framing/Sleepers must be Anchored*

16" OC - Residential Perpendicular Installation (*12" OC Recommended for Wood like Stiffness*)

12" OC - Heavy Traffic or Commercial Installs & 45° or Herringbone Layout

12" OC - All Stair/Step Stringers

INSTALLATION PROGRESSION: *For Best Results, Zuri Must be Installed in the Proper Sequence*

1) Main Body Deck Skirt Board

2) Main Body Deck Trim - Picture Frame Perimeter of Main Deck with Trim Board

3) Main Body of Decking - Inlay Field of Decking, Working Towards the Structure

4) Steps and Landings - Complete the Steps & Landings Using Same Procedures Outlined Above

COLOR MATCHED END COAT PAINT: 1 Bottle Coats Approximately 140 Ends & 2 Bottles per Job Minimum

Weathered Gray - Sherwin Williams - *2840 Hammered Silver*

Pecan - Sherwin Williams - *1112 Setter's Coat*

Walnut - Sherwin Williams - *1112 Setter's Coat*

Brazilia - Sherwin Williams - *6062 Rugged Brown*

Chestnut - Sherwin Williams - *6117 Smokey Topaz*

Hickory - Sherwin Williams - *6076 Turkish Coffee*

HEADCOTE CAP-TOR SCREWS: #10 x 2-1/2" - *Install in Vertical Surface of Trim & Face Fastener as Needed*

Weathered Gray - Tan Gray #31

Pecan - Cedar #81

Walnut - Brown #34

Brazilia - Mahogany #82

Chestnut - Buckskin #63

Hickory - Java #73

NOTE: 305 Stainless for Inland Builds & 316 Stainless for Coastal Applications
(Estimate 1 Screw/LF of Trim for Takeoff)
(Estimate 3 Screws)
(100, 350, 1,050 & 1,750 Count Boxes)

CAMO INSTALLATION TOOLS & SCREWS:

Camo Marksman Pro - Installs Zuri Deck Boards & 3/16" Spacing

Camo Marksman Pro-NB - Installs Zuri Trim Boards & 3/16" Spacing

Camo Marksman Edge - For Hard to Reach Spaces & No Spacing

Camo Screws - #7 x 1-7/8" - *Based on 16" OC & Nominal 6" Deck Boards*

100 Count Box - 25 Sq. Ft.

350 Count Box - 100 Sq. Ft.

700 Count Box - 200 Sq. Ft.

1,750 Count Box - 500 Sq. Ft.

NOTE: ProTech Coated for Inland Builds & 316 Stainless for Coastal Applications

INSTALLATION VIDEOS: <https://www.youtube.com> & Search "Zuri Premium Decking by Royal" for 5 Videos

INSTALLATION CHECKLIST: *Materials, Tools & Accessories Required for Every Zuri Deck Installation*

- **Zuri Deck Boards & Trim Cap**
- **Color Matched End Coat Paint**
- **Headcote Cap-Tor Screws**
- **Camo Tools & Screws**
- **2P-10 Activator & Adhesive** (*Only for Gluing Miters on Zuri Trim*)
- **Heavy Duty Clear PVC Cement** (*Only for Gluing Miters on Zuri Trim*)
- **Schedule Royal's 1st Nail 1st Board Installation Training**